

APPLICATION SYSTEM

01

STEP 1 — PREPARATION

Clean and dry the substrate before application.



Remove dust, dirt and loose debris



Eliminate standing water, oil and contaminants



Ensure the surface is sound, clean and dry

APPLICATION SYSTEM

02

STEP 2 — DETAILING

Reinforce seams, gaps and critical details.



Apply reinforcing fabric over joints and transitions



Embed the fabric fully into wet coating



Reinforce cracks, corners and penetration areas

APPLICATION SYSTEM

03

STEP 3 — COATING

Spray or roll DM-190 evenly over the roof surface.



Apply at the recommended thickness



Use spray or roller for uniform coverage



Allow proper curing for long-term protection